Smart PIR Sensor

Wi-Fi Security Device























DIY Installation of sensor.

Detects movement within a range of 4-6m.

BrilliantSmart app notification to device that movement has been detected.


Battery operated, no hub required:

CR123A x 1 (included)

Blue LED indicator.

Connects to other BrilliantSmart devices - reed switch, siren/alarm, camera or light via the app.

MODEL NO.	COLOUR
20708/05	WHITE





Smart Reed Switch

Wi-Fi Switch Connects to other Security Devices via App























Switch activates once door or window is opened/closed.


LED indicator.


BrilliantSmart app notification to phone or tablet that door or window has been opened/closed. App sounds alarm.

Battery operated, no hub required: $CR2-3V \times 1$ (included).

Connects to other BrilliantSmart devices – siren/alarm, sensor, camera or light via the app.

MODEL NO.	COLOUR
20714/05	WHITE






Smart Siren Alarm

Wi-Fi Security Device





















Can be triggered by BrilliantSmart reed switch, PIR sensor or camera. Loud sound when activated.

BrilliantSmart app notification to phone or tablet when siren is triggered. App sounds alarm.

Battery or USB operated, no hub required: CR123A-3V \times 2

(not included).

1m USB power cable.

LED indicator.

Sound level: up to 90dB.

Sound selection: up to 10 types.

Control from anywhere via BrilliantSmart app.

Connects to other BrilliantSmart devices – reed switch, sensor, camera or light via the app.

MODEL NO.	COLOUR
20712/05	WHITE

